

Fling on Raspberry Pi 4/Pi 5

Arm

Exported on 10/30/2024

Table of Contents

| | | |
|---------|---|----|
| 1 | Info | 5 |
| 2 | Required and supported hardware | 6 |
| 2.1 | Power Supply | 6 |
| 2.2 | Cooling | 7 |
| 2.3 | HDMI | 7 |
| 2.4 | HATs | 7 |
| 2.4.1 | PoE | 7 |
| 2.4.2 | M.2 HAT | 8 |
| 2.4.3 | Other HATs | 8 |
| 2.5 | Optional Serial Console | 8 |
| 2.6 | USB devices | 9 |
| 3 | Preparation | 10 |
| 3.1 | Ensure Raspberry Pi EEPROM is updated | 10 |
| 3.2 | Setup UEFI on SD Card | 12 |
| 3.2.1 | Download the necessary bits | 13 |
| 3.2.2 | Prepare SD card. | 13 |
| 3.2.2.1 | On Windows | 13 |
| 3.2.2.2 | On macOS | 15 |
| 3.3 | Decide on your console choice | 16 |
| 3.3.1 | Pi 4 Wiring | 16 |
| 3.3.2 | Pi 5 connector | 17 |
| 3.3.3 | Terminal emulator | 17 |
| 3.3.3.1 | 'screen' terminal emulator | 18 |
| 3.3.3.2 | 'minicom' terminal emulator | 18 |
| 3.4 | UEFI firmware configuration | 20 |
| 3.4.1 | Pi 4 Turn off 3GiB memory limit | 22 |
| 3.4.2 | Console Preference Selection | 23 |

| | | |
|---------|--|----|
| 3.4.3 | Raspberry Pi Display Configuration | 23 |
| 3.4.4 | Raspberry Pi CPU Configuration | 24 |
| 4 | Install ESXi-Arm | 25 |
| 4.1 | Power | 25 |
| 4.2 | Automated installation | 25 |
| 4.3 | Booting the installer | 25 |
| 4.3.1 | Installation target | 26 |
| 4.4 | Post install | 27 |
| 4.5 | NTP | 30 |
| 5 | Known issues | 31 |
| 5.1 | Hardware | 31 |
| 5.1.1 | Flaky USB in UEFI or ESXi | 31 |
| 5.1.1.1 | This is largely due to power issues | 31 |
| 5.1.1.2 | Plugging devices while system is on. | 31 |
| 5.2 | UEFI Firmware | 31 |
| 5.2.1 | Official Pi PoE hat fan doesn't work | 31 |
| 5.3 | ESXi-Arm | 31 |
| 5.3.1 | USB performance | 31 |



1 Info

The Raspberry Pi 4B is a credit-card size single board computer (SBC). It is based on the Broadcom BCM2711 SoC with 4 x Cortex-A72 and supports up to 8GiB RAM.

See <https://www.raspberrypi.org/products/raspberry-pi-4-model-b/specifications/>

The Raspberry Pi 5 is the successor to the Pi 4B and is based on the Broadcom BCM2712 SoC with 4 x Cortex-A76 and supports up to 8GiB RAM.

See <https://www.raspberrypi.com/products/raspberry-pi-5/>

Both the Pi4B and Pi5 have USB3 and GbE connectivity.

The anticipated use case is "Far Edge": e.g. a virtualized IoT gateway.

2 Required and supported hardware

Minimally, you need:

- A good power supply
- Raspberry Pi 4 Model B 8GiB or Raspberry Pi 5 8GB
 - (1GiB, 2GiB and 4GiB are not supported)
- 1 x micro SD card for UEFI firmware
- 1 x USB drive for installer ISO
- 1 x USB drive or SATA / NVMe adapter and drive for the actual ESXi installation
- Console selection
 - HDMI + USB keyboard
 - UART (serial) cable

The following hardware is supported:

- Pi 5 Pi M.2 HAT+
- PI 4B On-board GbE NIC (recommended)
- USB networking (required on the Pi 5)
- HDMI video
- Serial console
- USB storage
- USB keyboard
- PoE HAT

As you will note, SD card is not supported by ESXi. It is only used to keep the UEFI firmware. On the Pi5 with an M.2 HAT+ and an NVMe drive the SD card can be replaced if UEFI is provided on the NVMe drive.

The following hardware is not supported currently:

- PI 5 On-board GbE NIC

2.1 Power Supply

A good power supply is critical, especially for using USB storage.

| Description | Amps | Product |
|--|------|---|
| Argon ONE Raspberry Pi 4 USB Type C Cable Power Supply | 3.5 | https://www.amazon.com/gp/product/B07TW4Q693 |
| CanaKit 3.5A Raspberry Pi 4 Power Supply | 3.5 | https://www.amazon.com/CanaKit-Raspberry-Power-Supply-USB-C/dp/B07TYQRXTK |

| Description | Amps | Product |
|--|------|---|
| Raspberry Pi official 27W Power Supply | 5.0 | https://www.raspberrypi.com/products/27w-power-supply/ |

2.2 Cooling

It is highly recommended to perform active cooling. The Pi runs hot. Passive cooling (heatsinks) help here, but so will a nice quiet 5V Noctua fan. Cooling and cases are highly individual and may involve some handywork.

2.3 HDMI

Use a micro-HDMI adapter or cable like <https://www.amazon.com/CanaKit-Raspberry-Micro-HDMI-Cable/dp/B07TTKD38N>.

2.4 HATs

2.4.1 PoE

These can be used for building clusters of Pies. Note that it is highly recommended to provide additional active cooling. PoE HATs make an already hot Pi run even hotter, without any space for passive cooling elements and (at best) puny fans.

| Description | Product | Comments |
|---|---|---|
| GeeekPi Raspberry Pi 4 PoE HAT | https://www.amazon.com/gp/product/B0833PP65P | Fan works. Largest fan so far seen on a PoE hat and there is space for heatsinks. |
| UCTRONICS PoE HAT for Raspberry Pi 4 | https://www.amazon.com/UCTRONICS-Raspberry-Ethernet-Expansion-Cooling/dp/B082ZJYCS3 | Fan works. No space for heatsinks. |
| Official Raspberry Pi Power Over Ethernet | https://www.amazon.com/poe-hat/dp/B07GR9XQJH | Fan doesn't spin due to missing UEFI support. No space for heatsinks. Must use external cooling! |

2.4.2 M.2 HAT

| Description | Product | Comments |
|---------------------------|---|----------------------|
| Official Pi 5 Pi M.2 HAT+ | https://www.raspberrypi.com/products/m2-hat-plus/ | Not all drives work. |

2.4.3 Other HATs

Not supported. This includes any kind of I2C, SPI or GPIO extension or connectivity.

2.5 Optional Serial Console

ESXi-Arm on Pi is entirely usable via HDMI + USB keyboard, yet for developers and power users alike, the importance of a serial connection cannot be overstated. In ESXi it gives you convenient access to system log, console and basic management interface (DCUI), especially if you chose to operate your Pi headless.

Note: Get a USB-to-TTL serial cable. The cable must be for 3.3V, not 5V.

| V I D | P I D | Description | Product | Comments |
|------------------|------------------|---|--|----------|
| 0 4 0 3 | 6 0 0 1 | DTECH FTDI USB to TTL Serial 3.3V Adapter Cable | https://www.amazon.com/dp/product/B07RBKCW3S ¹ | |

The Pi5 has a special connector for the default UART. The following can be purchased to connect

| Description | Product | Comments |
|--|---|---------------|
| Official Raspberry Pi Debug Probe | https://www.raspberrypi.com/products/debug-probe/ | Multi-purpose |
| Waveshare USB To UART Debugger Module for Raspberry Pi 5 | https://www.waveshare.com/pi-uart-debugger.htm | untested |

¹ <https://www.amazon.com/dp/product/B07RBKCW3S/>

2.6 USB devices

IMPORTANT: USB device can consume significant power and thus put a stress on Pi's power circuits. Some USB devices can consume so much power (e.g. NVMe enclosure) that the Pi will simply not work, be unstable or have unstable USB behavior. For anything short of a basic USB key, use a powered USB3 hub.

Note: Some of these USB devices have Type-C plugs. The expectation is that they will be plugged (directly or via hub) into the front (USB3) ports. Use a mechanical adapter such as <https://www.amazon.com/gp/product/B07LF72431>. Do not plug these into the Type-C port on the Pi for performance reasons.

See the lists and notes in the main ESXi-Arm Fling Doc.

3 Preparation

Setup involves ensuring Raspberry Pi microcode (e.g. for USB) is up-to-date, deploying the UEFI firmware and preparing the installer USB drive.


3.1 Ensure Raspberry Pi EEPROM is updated


This is critical to a stable USB experience and reasonable temperatures. Thanks to Florian Grehl of Vitrten.net who initially shared this simplified procedure.

You need:

- SD Card
- HDMI Screen (optional)
- Raspberry Pi Imager Tool for your OS: <https://www.raspberrypi.org/downloads/>

Deploy the Raspberry Pi 4 EEPROM boot recovery onto the SD card:





Plug SD card into the Pi and power up device, eventually with HDMI screen connected. From the EEPROM bootloader rescue documentation:

"If successful, the green LED light will blink rapidly (forever), otherwise an error pattern will be displayed.

If a HDMI display is attached then screen will display green for success or red if failure a failure occurs."

3.2 Setup UEFI on SD Card

The SD card will be only used for UEFI firmware, so don't bother with a big card. The SD card is required, and configurations where the UEFI firmware is booted from USB or network are not covered here or supported.

3.2.1 Download the necessary bits

- Download the [latest official Raspberry Pi Firmware](https://github.com/raspberrypi/firmware/archive/master.zip)² and extract the contents to your computer, you should have a folder called **firmware-master**. This corresponds to the microcode necessary to initialize the Raspberry Pi.
- Download the UEFI firmware that is necessary to boot ESXi-Arm
 - [latest community Raspberry Pi 4 UEFI firmware](https://github.com/pftf/RPi4/releases)³ and extract the contents you should have a folder called **RPi4_UEFI_Firmware_v1.38**.
 - [latest community Raspberry Pi 5 UEFI firmware](https://github.com/worproject/rpi5-uefi/releases)⁴ and extract the contents you should have a folder called **RPi5_UEFI_Release_v0.3**.

3.2.2 Prepare SD card.

Format the SD card with a single FAT32 (MSDOS) partition. If you just used the SD Card to update the EEPROM, you just need to delete the recovery files.


3.2.2.1 On Windows

Open up Windows Explorer and identify the SD Card and select "Format" and create FAT32 partition. In the example below, the partition label is called UEFI:

² <https://github.com/raspberrypi/firmware/archive/master.zip>

³ <https://github.com/pftf/RPi4/releases>

⁴ <https://github.com/worproject/rpi5-uefi/releases>



Copy all the files in the extracted folder the newly formatted SD card:

3.2.2.1.1 Pi5

| Name | Type | Compressed size |
|---------------------|---------------|-----------------|
| bcm2712-rpi-5-b.dtb | DTB File | 17 KB |
| config | Text Document | 1 KB |
| RPI_EFI.fd | FD File | 1,207 KB |

3.2.2.1.2 Pi4

| Name | Type | Compressed size |
|---------------------|---------------|-----------------|
| firmware | File folder | |
| overlays | File folder | |
| bcm2711-rpi-4-b.dtb | DTB File | 13 KB |
| bcm2711-rpi-400.dtb | DTB File | 13 KB |
| bcm2711-rpi-cm4.dtb | DTB File | 13 KB |
| config | Text Document | 1 KB |
| fixup4.dat | DAT File | 2 KB |
| Readme.md | MD File | 3 KB |
| RPI_EFI.fd | FD File | 1,555 KB |
| start4.elf | ELF File | 1,297 KB |

Eject the SD Card and then put the SD card into the Pi.

3.2.2.2 On macOS

Identify the disk using the following command and make note of the disk path (e.g. /dev/diskX):

```
$ diskutil list

/dev/disk6 (internal, physical):
#           TYPE NAME              SIZE       IDENTIFIER
0:         FDisk_partition_scheme  *63.9 GB   disk6
1:          Windows_FAT_32 boot      268.4 MB   disk6s1
2:           Linux                  63.6 GB    disk6s2
```

Create FAT32 partition on the SD Card by running the following command and providing disk path. The partition label will be called **UEFI**, you can choose another name if you wish:

```
$ diskutil partitionDisk /dev/disk6 1 MBRFormat "MS-DOS" UEFI R
```

Copy all files within the **RPI4_UEFI_Firmware_v1.38** or **RPI5_UEFI_Firmware_v0.3** directory into the same boot directory on SD card, e.g.:

```
cp -rf ~/Downloads/RPi4_UEFI_Firmware_v1.38/* /Volumes/UEFI
```

Eject the SD Card:

```
diskutil eject /dev/disk6
```

Now put the SD card into the Pi.

3.3 Decide on your console choice


The choices are:

- HDMI + USB keyboard (if you choose this option, skip to 3.4)
 - Required to update Raspberry Pi's microcode EEPROM via Pi OS
 - Access to UEFI setup
 - Preferred for installing ESXi-Arm
- Serial console
 - Access to UEFI setup
 - Supported for installing ESXi-Arm

If you choose HDMI and a USB keyboard, **make sure to use the leftmost HDMI port.**

If you chose to wire up the serial port, connect the cable to the UART pins on the board. The three pins you would need to connect are GND, TX and RX.


3.3.1 Pi 4 Wiring



Note the connections are as follows, with the TX pin on the cable going to the RXD and vice-verse. If you get this wrong, you will see no output.


- Black (GND) → GND (Ground, pin 6)
- Green (RX) → TXD (GPIO 14, pin 8)
- White (TX) → RXD (GPIO 15, pin 10)

3.3.2 Pi 5 connector



3.3.3 Terminal emulator

WARNING: the ESXi installer requires the F11 key press and this can be mapped by, for example, macOS system settings. Ensure this is disabled



Fire up your terminal emulation and connect to the device on your PC. The parameters used to open this port:

```
Baud Rate    → 115200
Data Bits    → 8
Parity       → None
Stop Bits    → 1
Flow Control → None
```

3.3.3.1 'screen' terminal emulator

Note: device names below may be different. Check your system.

On Linux:

```
$ screen /dev/ttyUSB0 115200
```

On macOS:

```
$ screen /dev/tty.usbserial-A900UE2E
```

3.3.3.2 'minicom' terminal emulator

Note: device names below may be different. Check your system.

With **minicom**, you will have to configure settings the first time you use it. To access menus, you will have to use the **CTRL** key in Linux, and **ESC** key on macOS. These directions will refer to this key as **META**.

On Linux:

```
$ minicom -c on -D /dev/ttyUSB0
```

On macOS:

```
$ minicom -c on -D /dev/tty.usbserial-A900UE2E
```

Now press **META-Z**:



```

Welcome-----
|                                     |
|               Minicom Command Summary               |
|-----|-----|-----|-----|-----|-----|-----|
| OPTION|                                     |
| Compil|                                     |
| Port //|                                     |
| Press |                                     |
|-----|-----|-----|-----|-----|-----|-----|
|                                     |
|               Main Functions               |               Other Functions               |
|-----|-----|-----|-----|-----|-----|-----|
| Dialing directory..D | run script (Go)....G | Clear Screen.....C |
| Send files.....S   | Receive files.....R | cOnfigure Minicom..O |
| comm Parameters....P | Add linefeed.....A | Suspend minicom....J |
| Capture on/off....L | Hangup.....H   | eXit and reset....X |
| send break.....F   | initialize Modem...M | Quit with no reset.Q |
| Terminal settings..T | run Kermit.....K | Cursor key mode....I |
| lineWrap on/off....W | local Echo on/off..E | Help screen.....Z   |
| Paste file.....Y   | Timestamp toggle...N | scroll Back.....B   |
| Add Carriage Ret...U |                                     |
|                                     |
|               Select function or press Enter for none. |
|-----|-----|-----|-----|-----|-----|-----|
|                                     |
| Meta-Z for help | 115200 8N1 | NGR | Minicom 2.7.1 | VT102 | Offline | 1-A900UE2E |

```

Now press **O**:

```

Welcome to minicom 2.7.1

OPTIONS:
Compiled on Oct  6 2019, 23:16:03.
Port /dev/tty.usbserial-A900UE2E, 23:35:36

Press Meta-Z for help on special keys

+-----[configuration]-----+
| Remove and pathc           |
| File transfer protocols    |
| Serial port setup          |
| Modem and dialing          |
| Screen and keyboard        |
| Save setup as df1          |
| Save setup as..            |
| Exit                        |
+-----+

Meta-Z for help | 115200 8N1 | NOR | Minicom 2.7.1 | VT102 | Offline | 1-A900UE2E

```

Use arrow key to navigate to **Serial port setup** and press the **ENTER**:

```

Welcome to minicom 2.7.1

OPTI+-----+
Comp| A -   Serial Device       : /dev/tty.usbserial-A900UE2E   |
Port| B - Lockfile Location    : /usr/local/Cellar/minicom/2.7.1/var |
Pres| C - Callin Program       :                               |
     | D - Callout Program      :                               |
     | E - Bps/Par/Bits        : 9600 8N1                       |
     | F - Hardware Flow Control : No                           |
     | G - Software Flow Control : No                           |
     |                               |
     | Change which setting? |
+-----+
| Screen and keyboard    |
| Save setup as df1      |
| Save setup as..        |
| Exit                   |
+-----+

Meta-Z for help | 9600 8N1 | NOR | Minicom 2.7.1 | VT102 | Offline | ial-A900UE2E

```

Now press **E**:

```

Welcome to minicom 2.7.1

OPTI+-----+-----[Comm Parameters]-----+-----+
Comp| A -   Serial De|                               |E|
Port| B - Lockfile Loc| Current: 9600 8N1           |2.7.1/var|
Pres| C - Callin Pro| Speed      Parity      Data |
     | D - Callout Pro| A: <next>    L: None    S: 5 |
     | E - Bps/Par/B| B: <prev>    M: Even   T: 6 |
     | F - Hardware Flo| C: 9600     N: Odd    U: 7 |
     | G - Software Flo| D: 38400    O: Mark   V: 8 |
     |                               | E: 115200   P: Space |
     |                               |
     | Change which |
+-----+ Stopbits
| Screen a| W: 1      Q: 8-N-1 |
| Save set| X: 2      R: 7-E-1 |
| Save set|               |
| Exit    |               |
+-----+ Choice, or <Enter> to exit? |
+-----+

Meta-Z for help | 9600 8N1 | NOR | Minicom 2.7.1 | VT102 | Offline | ial-A900UE2E

```

Press **E** again, then **ENTER**.

```

Welcome to minicom 2.7.1

OPTI+-----+
Comp| A -   Serial Device       : /dev/tty.usbserial-A900UE2E |
Port| B - Lockfile Location     : /usr/local/Cellar/minicom/2.7.1/var |
    | C -   Callin Program      : |
Pres| D - Callout Program        : |
    | E -   Bps/Par/Bits        : 115200 8N1 |
    | F - Hardware Flow Control : No |
    | G - Software Flow Control : No |
    | |
    | Change which setting? |
+-----+
    | Screen and keyboard |
    | Save setup as dfl   |
    | Save setup as..    |
    | Exit                |
+-----+

Meta-Z for help | 115200 8N1 | NOR | Minicom 2.7.1 | VT102 | Offline | 1-A900UE2E

```

Make sure settings **F** and **G** both say **No** to any kind of flow control. Press **ENTER** when done, then navigate to **Save setup as dfl** and press **ENTER**.

```

Welcome to minicom 2.7.1

OPTIONS:
Compiled on Oct  6 2019, 23:16:03.
Port /dev/tty.usbserial-A900UE2E, 23:35:36

Press Meta-Z for help on special keys

+-----[configuration]-----+
| Filenames and paths |
| File transfer protocols |
| Serial port setup |
| Modem and dialing |
| Screen and keyboard |
| Save setup as dfl |
| Save setup as.. |
| Exit |
+-----+

Meta-Z for help | 115200 8N1 | NOR | Minicom 2.7.1 | VT102 | Offline | 1-A900UE2E

```

Use **ESC** to exit out of the menus.


3.4 UEFI firmware configuration

You can use either HDMI + USB keyboard or a serial console. The output is duplicated to both. To enter UEFI setup, apply power to the Raspberry Pi, then keep mashing the **ESC** key when prompted.

With an HDMI screen, this is when you see the Raspberry Pi logo.



With a serial console, this is when you see this:



In either case, the output will be identical - the configuration home page:



3.4.1 Pi 4 Turn off 3GiB memory limit

The Raspberry Pi 4 UEFI is configured with a default limit of 3GiB of memory for OS compatibility purposes. This will prevent the ESXi installer from proceeding, and needs to be turned off.

Using arrow keys, first navigate to **Device Manager**:

```

Select Language      <English>      This selection will
                                     take you to the
> Device Manager
> Boot Manager
> Boot Maintenance Manager

```

Press **ENTER** and navigate to **Raspberry Pi Configuration**:

```

Device Manager
-----
Devices List
> Secure Boot Configuration
> Console Preference Selection
> RAM Disk Configuration
> Driver Health Manager
> Tls Auth Configuration
> Raspberry Pi Configuration
> iSCSI Configuration
> Network Device List
                                     Press <Enter> to
                                     configure system
                                     settings.

```

Press **ENTER** and navigate to **Advanced Configuration**:

```

Raspberry Pi Configuration
-----
> CPU Configuration
> Display Configuration
> Advanced Configuration
> SD/MMC Configuration
> Debugging Configuration

```

The **Limit RAM to 3GB** setting should already be selected, as it is the first setting on the page:

```

Advanced Configuration
-----
Limit RAM to 3 GB      <Enabled>
System Table Selection <ACPI>
ACPI fan control       <Disabled>
ACPI fan temperature  [60]
Asset Tag              -
                                     OSeS not supporting
                                     ACPI DMA constraints
                                     require a 3 GB limit
                                     or face broken xHCI
                                     USB

```

Press **ENTER** and use arrow keys to select **Disabled**:


```

Advanced Configuration
-----
Limit RAM to 3 GB      <Enabled>
System Table Selection <ACPI>
ACPI fan control       <Disabled>
ACPI fan temperature  [60]
Asset Tag              -
                                     OSeS not supporting
                                     ACPI DMA constraints
                                     require a 3 GB limit
                                     or face broken xHCI
                                     USB

```

Disabled
Enabled

Press **ENTER** again, then **F10** to save settings:



Press **Y**, then **ESC** three times to get back to the home page. Then navigate to **Continue** and press **ENTER**.




Press **ENTER** again. The Pi will reboot.

3.4.2 Console Preference Selection

The console preference setting only matters if you have an HDMI screen connected to the Pi. If the screen is not connected, the serial port will be exposed to the booted OS, and ESXi will use it as it will detect a headless mode.



If the HDMI screen is connected, the serial port will not be exposed to the booted OS by default. Change the setting to Serial if you want to use the serial port in ESXi.



3.4.3 Raspberry Pi Display Configuration

The display settings can be used to force a particular resolution to improve legibility:

```

/----- Raspberry Pi Configuration -----\
|
| > CPU Configuration
| > Display Configuration
|
\-----/

```

For example, with a small screen this may work well:

```

/----- Display Configuration -----\
|
| UEFI video driver settings
| Virtual 640x480      [ ]      Enable scaled 640x480
| Virtual 800x600      [X]      mode
| Virtual 1024x768     [X]
| Virtual 1280x800     [ ]
|
\-----/

```

3.4.4 Raspberry Pi CPU Configuration

It is not recommended to mess with these. Regardless of the MHz reported, the Pi won't go over 1500 without additional settings in **config.txt** on the SD card.

Note: do not overclock. Not only are you compromising stability, but memory and I/O performance may suffer up to 2x.

```

/----- CPU Configuration -----\
|
| Note: OS may override settings.
| CPU Clock      <Default>      CPU Speed
| CPU Clock Rate (MHz) [1500]
|
\-----/

```


4 Install ESXi-Arm

Follow the generic installation steps, with a few caveats.

On the Raspberry Pi, ESXi only supports installation to USB storage or iSCSI LUNs.

It is recommended to use HDMI video + USB for installation itself. If you need to pass any advanced options to installer (e.g. via **Shift-O** in the ESXi bootloader), this cannot be done using serial console today.



E.g. Append **systemMediaSize=min** (the supported option for smallest OSData volume) or **autoPartitionOSDataSize=8192** (not officially supported) for an 8GB VMFS-L partition, and the rest available for a datastore.

For more details on changing the default OSData volume, please see this [blog post](#)⁵.

4.1 Power


Make sure to use a solid power supply. If plugging in USB NICs or any storage beyond a very basic USB thumb drive, consider using a powered USB hub.

4.2 Automated installation

If using a kickstart script, the NIC name for onboard GbE is **vmnic128**.


4.3 Booting the installer

Plug in the USB key with installer into the Pi, and power on (or cycle) the Pi. Enter UEFI configuration by mashing the **ESC** key. Then, use the arrow keys to navigate to **Boot Manager**:




⁵ <https://www.virtuallyghetto.com/2020/05/changing-the-default-size-of-the-esx-osdata-volume-in-esxi-7-0.html>

Press **ENTER**, then navigate to the USB drive with the installer.



Press **ENTER**, and the installer will boot:




You should be able to follow the generic installation steps.

Note: If you're using the official Raspberry Pi USB keyboard, **F11** is the combination of **Fn** and **F1**.


4.3.1 Installation target

The easiest way to install ESXi is to use a USB stick as installation target. You can re-use the USB stick that you booted the installer from (it will be overwritten), or insert a second USB stick that you install ESXi on.

When asked for a ESX OSData store when installing on a USB attached disk simply press enter to skip this step.



and confirm this choice in the next dialog.



You also can install on a remote iSCSI target, which requires some additional setup in the Raspberry Pi UEFI. See the main Fling document.

4.4 Post install

The Pi does not have real NVRAM for UEFI boot settings. This means that operating systems like ESXi have read access to the NVRAM, but not write access. The side-effect here is that the ESXi installer will not be able to update boot options, and boot into ESXi may take a really long time as other boot options fail.

After ESXi install completes, remove the install USB drive. After the system reboots, re-enter UEFI setup and navigate to **Boot Maintenance Manager**:

```

Raspberry Pi 4 Model B
BCM2711 (ARM Cortex-A72)      1.50 GHz
UEFI Firmware v1.20           8192 MB RAM

Select Language      <English>      This selection will
                                   take you to the Boot
                                   Maintenance Manager
> Device Manager
> Boot Manager
> Boot Maintenance Manager

```

Press **ENTER** and select **Boot Options**:

```

/-----
|                               Boot Maintenance Manager
|-----
> Boot Options                  Modify system boot
> Driver Options                options
> Console Options
> Boot From File

Boot Next Value      <NONE>

```

Press **ENTER** and select **Change Boot Order**:

```

/-----
|                               Boot Options
|-----
> Go Back To Main Page          Will be valid
> Add Boot Option               immediately
> Delete Boot Option
> Change Boot Order

```

Press **ENTER** twice, and use arrow keys to navigate to the only USB drive you see:


```

Change the order      <SD/MMC on Arasan SDHCI>      Change the
                     <UEFI PXEv4
                     (MAC:DCA632B1E629)>


/-----
| SD/MMC on Arasan SDHCI
| UEFI PXEv4 (MAC:DCA632B1E629)
| UEFI PXEv6 (MAC:DCA632B1E629)
| UEFI HTTPv4 (MAC:DCA632B1E629)
| UEFI HTTPv6 (MAC:DCA632B1E629)
| UEFI Samsung Flash Drive FIT 0377319070025344
|-----

```


Keep pressing the **+** key until the drive is at the top of the list. You definitely want to skip any network options as they take a long time to time out.



Press **ENTER** to complete the selection.



Now navigate to **Commit Changes and Exit**:



Press **ENTER** and **ESC** out as before to the main UEFI setup screen. Navigate to **Continue**:

```
Raspberry Pi 4 Model B
BCM2711 (ARM Cortex-A72)      1.50 GHz
UEFI Firmware v1.20          8192 MB RAM

Select Language      <English>      Continue

> Device Manager
> Boot Manager
> Boot Maintenance Manager

Continue
Reset
```

ESXi will boot.

4.5 NTP

The Pi does not have a battery backed RTC. Consequently, its notion of time will reset back to the UEFI firmware build date on every boot. Thus, you **must** configure NTP if you wish to add the Pi to a vCenter (ideally, matching the NTP servers used by vCenter to avoid time skew issues).

5 Known issues

5.1 Hardware

5.1.1 Flaky USB in UEFI or ESXi

I/O errors, device not enumerating or disappearing (works in UEFI, not ESXi).

5.1.1.1 This is largely due to power issues.

Workaround: Use a powered hub, especially if using power hungry USB-SATA or USB-NVMe enclosures, or USB NICs with embedded USB hubs.

5.1.1.2 Plugging devices while system is on.

The USB3 implementation on the Pi is a bit sensitive. Could also be due to power fluctuations.

Workaround: Avoid hot plugging devices directly into the Pi if you can.

5.2 UEFI Firmware

5.2.1 Official Pi PoE hat fan doesn't work

See <https://github.com/pftf/RPi4/issues/101>.

Workaround: Either use a different PoE hat or provide active cooling (recommended regardless).

5.3 ESXi-Arm

5.3.1 USB performance

USB3 implementation quirks in the Raspberry Pi 4 and their ESXi workarounds mean significant overhead for some kinds of I/O, such as USB NICs or USB devices pass-through to VMs. USB GbE NICs are known to top out at 200mbps.

Workaround: Use the onboard GbE NIC if possible.